

OVAL

FITTING INSTRUCTIONS

TOOLS REQUIRED

5MM ALLEN KEY
16MM OR 5/8 OFFSET SPANNER

- 1 Attach Legs to bottom of rack as per diagram. DO NOT FULLY TIGHTEN
- 2 Set legs, width wise, roughly 135 cm apart.
- 3 Attach plastic protector to gutter support.
- 4 Attach gutter support to legs.
- 5 Place rack on vehicle ensuring legs sit inside gutter channel.
- 6 Attach clips to legs. Refer to diagram.
- 7 Centralise roof rack on vehicle.
- 8 Tighten clip bolts with 5mm Allen Key.
- 9 Tighten hex head bolts under legs with offset spanner.

